



**OSCARTEK®**

# METRO

## GELATO/ICE CREAM



(E)

## Maintenance And Use Manual



**OSCARTEK**

512 South Airport Blvd.  
South San Francisco, CA 94080  
Tel: 855.885.2400 | 650.342.2400  
Fax: 650.342.7400  
[www.oscartek.com](http://www.oscartek.com)  
[sales@oscartek.com](mailto:sales@oscartek.com)

## 1. INTRODUCTION

### PRESENTATION

Dear Client,

Oscartek is pleased to number you among its customers and relies the bought machine will match your expectation. In order to get the best performances of the machine, we recommend you to follow all suggestions and instructions, which are included in this manual.

## 1.2. HOW TO USE THE MACHINE

### ▪ PERMITTED USES

This refrigerated display cabinet has been manufactured for **ice cream** presentation and sell.

### ▪ NOT PERMITTED USES

It is absolutely forbidden the use of the refrigerated display cabinet for **pharmaceutical products**.

## 1.3. RESPECTED NORMS

The refrigerated display cabinet has been manufactured in respect of the safety issues relevant to the following norm:

- |                                      |                                                              |
|--------------------------------------|--------------------------------------------------------------|
| ➤ Machinery Directive N° 2006/42/CE  | : CE marking for machinery                                   |
| ➤ Directive N° 2006/95/CE            | : Low tension                                                |
| ➤ Directive N° 2004/108/CE           | : Electro-magnetic Compatibility                             |
| ➤ Directive N° 97/23/EC (P.E.D.)     | : European Pressure Equipment                                |
| ➤ Norm CEI 17-13/1 (EN 60439/1)      | : Realization of Electric Installations                      |
| ➤ Norm CEI EN 60335-1 (CEI 61-150)   | : Safety of household and similar electrical appliances      |
| ➤ Norm CEI EN 60335-2-24 (CEI 61-56) | : Special norms for refrigerators, freezers and ice machines |

For ETL marked cabinet:

- |                                     |
|-------------------------------------|
| ➤ UL471 / CAN/CSA C22.2 No. 120-M91 |
| ➤ NSF/ANSI 7 - 2009                 |

## 1.4. RESPONSIBILITY

Oscartek declines any responsibility relevant to damages on persons, animals and/or products in case of:

- No respect of in force norms
- Installation, which is not conform to the instructions manual
- No observance of all maintenance operations, which are suggested in this manual
- No previously agreed change operations with the manufacturer
- No proper use of the refrigerated display cabinet, for which the machine has been produced.

## 1.5. WARNING

Anytime Oscartek reserves the right to up-date the content of this manual and/or to modify the product in order to improve its quality and performance, without any previous notice and/or communication.

## 2. DISPLAY CASE DATA PLATE

### 2.1. DATA PLATE CONTENT

 OSCARTEK®		 OSCARTEK® www.oscartek.com
<b>Model</b> 1	<b>Production Date</b>	
<b>Serial No.</b> 2	3	
 4 V/ 5 ph / 6 Hz	14	W/A
 Type 7	15	W
 No. 8	16	W
<b>Gas</b> 9	10	<b>Kg</b> Cl. 11
 Pmax 12 psig	 Pmin 13 psig	17 W
SAMPLE		
1. Commercial name of the unit	10. Refrigerant weight	
2. Identification number	11. Climatic rate (Cl.3 = +25°C/60% U.R.; Cl. 4 = +30°C/55% U.R.)	
3. Production date	12. Test pressure – system high pressure side	
4. Voltage	13. Test pressure – system low pressure side	
5. Phases	14. Nominal power/current absorbed during defrost	
6. Frequency	15. Max. power absorbed during defrost	
7. Compressor type	16. Nominal power absorbed by heating elements (only if higher than 100W)	
8. Number of compressor	17. Lighting nominal power	
9. Refrigerant type		

---

### **3. INSTALLATION**

#### **3.1. MACHINE HANDLING**

- The ice cream display cabinet handling, from the truck to the final place, has to be made by any truck-lift, which is proper to its weight. The display cabinet shall be always balanced in order to ensure personnel integrity and machine functionality
- The cabinet can be shipped with or without wood packaging, in case wood crate will be used, will have a pallet base for an easy fork-lift handling. The pallet, however should be handle in the central position
- During the shipment, it is necessary to avoid any crash or/and shake of the display cabinet in order to not damage its frame, especially its glasses.
- Do not drag the display cabinet on the floor and do not push it on the upper glasses.

#### **3.2 STOCK OF THE DISPLAY CABINET**

- Whenever the cabinet has to be stoked, follow carefully what suggested before.
- Environmental temperature during the cabinet stock can have following range -15°C and + 55°C and humidity between 30% and 90%.
- The display cabinet has always to be protected by sunrays and raining.
- In case the display cabinet has to remain in stock quite long time before its use, keep it with its packaging in order to maintain its protection.

#### **3.3. PACKAGING REMOVE**

Before getting the display cabinet from the forwarding agent, check its conditions. In case it will be some damages, inform the driver and sign it on shipping documents. **Eventual damages relevant to the shipment and/or to the wrong stock, have not to be ascribed to the manufacturer.**


#### **3.4. DISPLAY CABINET POSITION**

The refrigerated display cabinet needs particular environmental conditions in order to offer the right performance, so that the area where it will be used has to respect following indications

- Floor has to be levelled perfectly, on the contrary keep the display cabinet on the horizontal position in order to guarantee a perfect defrosting water drain and avoid boring compressor noises.
- The display cabinet has to not be under the sun-rays in order to have its better refrigeration performance, has to remain inside the local or to be sheltered by window curtain. If what described above is not observed, it can determinate an increase of temperature of displayed product and an increasing power consume.  
In case will be not respected the above suggestions it can arise an increasing of temperature of the displayed product and/or an increasing ice phenomena on the evaporator and internal fans, which compromise the correct cold air circulation and product consistence
- The display cabinet has not to be under air currents due to open doors or windows, or under roof ventilators or under air condition outlets.
- The display cabinet has not to be placed close any heat source as heaters, ovens, etc
- The display cabinet has to have a sufficient place in order to ensure a correct custom service, to make an easy maintenance operation, to guarantee the right air flow necessary to make cold the condenser. Besides the warm air which flows out has to no have any obstacle or to invest other equipments in order to not reduce the correct functions.

### 3.5. REMOTE CONDENSING UNIT PLACING

- According to the model of ice cream display cabinet you have No.1 or No.2 internal, or remote, condensing units.
- The remote condensing unit has to be checked by specialised technicians and according to the required refrigerating power and their position respect the cabinet. The condensing unit has to be placed following these points:
  - The condensing unit has to be located at least 250 mm from any eventual wall. (pic.3.1)
  - Air flow direction has to be from the eventual wall towards compressor.
  - The local, in case will be closed, has to be with enough air circulation.
  - By the condenser has to be guaranteed in any case as much as possible cold air.
  - In case will be necessary it has to be foreseen a forced air exchange by any fan according to the air flow of condenser.
  - The condensing units of display cabinets have to be fixed properly.
  - The generated noise has not exceed the admitted noise levels relevant to the public places, especially in case of domestic buildings.
  - It is always necessary a sufficient place along the four sides of the display cabinet in order to make easy any type of check and maintenance operations.
  - When the condensing units are external will be necessary a frame holder that has to be fixed in a proper way and eventually added with amortising elements. Besides this frame has to be closet with no-water protection grid and sufficient opening holes for ventilation.



pic.3.1

### 3.6 PIPING CONNECTION BETWEEN DISPLAY CABINET AND REMOTE CONDENSING UNITS.

- The liquid and suction piping exit from the base of the display cabinet in the left side of the base. The choice of piping diameter and insulation thickness has to be taken by specialised technical personnel, who know specific parameters.
- The choice of piping diameter and insulation thickness has to be taken by specialised technical personnel, who know specific parameters.
- The piping length has to be as short as possible.
- The piping arrangement has to be made on purpose by qualified personnel in order to guarantee the main functionalities as the right inclination, to have some siphons on the base of suction piping on the way up, and eventually on the intermediate elevation.

**WARNING!** A wrong connection may occur serious damages on the display cabinet, especially on the compressor. The display cabinet manufacturer cannot be responsible of any damage, which can arise from a wrong connection made by third parties.

### 3.7 ELECTRICAL CONNECTION


- Before proceeding with electrical connection, be sure that the available electric power and tension are what is required on technical label of the cabinet.
- The electric connection has to be made by qualified personnel and following manufacturer's instructions taking into consideration the relevant norms in force.
- The display cabinet has already a general switch, however it is necessary an omni polar switch, with a minimum distance among the contacts of 3mm.
- It is obligatory that the display cabinet will be connected properly with an efficient ground socket.

**WARNING!** A wrong connection may occur always to persons, animals and things, where the manufacturer cannot be considered as responsible.

**WARNING!**

The display cabinet has main switch breaking both the phases.

However before any maintenance operation disconnect the electrical supply of the display cabinet. (pic.3.3).



pic.3.3

---

### **3.8 – ELECTRICAL CONNECTION – REMOTE CONDENSING UNIT**

In case the display cabinet has a remote condensing unit, the external electrical box is supplied separately; in case the display cabinet is without condensing unit, the machine can be supplied without external electrical box. However the electrical connection has to be made connecting terminal are numbered and represent:

- 1-2 Electrical supply
- 3-4 Compressor switch
- 5-6 Defrosting switch
- G Ground connecting terminal

### **3.9. IDRAULIC CONNECTION**

- In case the display cabinet has an internal condensing unit by air, it is not necessary any water system connection.
- In case the display cabinet has a dipper well, it is necessary make the connection of its water outlet with the main water drain outlet; besides it is necessary set a load water tube to the dipper well, to the operator side, to the right or to the left, according to customer's choice.
- In case the display cabinet has condensing unit working fully or partially by water, it is necessary to connect the load water tube (this is the tube with thermo insulation) with the unload water tube (this is the tube without thermo insulation), of condenser working by water, to the water line

### **3.10. IDRAULIC CONNECTION - REMOTE CONDENSING UNIT**

- In the case then display cabinet has a remote condensing unit, it is necessary make the connection of defrosting water outlet with the main water drain outlet. Below the cabinet there is a female pipe-fitting with a rapid receptacle for a tube Ø 32 mm

## 4. WORKING

### 4.1. PRELIMINARY STEPS


- Model with built-in system. Before delivery to customer, it is very important that technicians will verify the correct functioning of the unit, so to obtain best possible efficiency
- Model with remote condensing unit. Please proceed as per previous point and carry out the following operations with accuracy:
  - Verify, when the unit is out, that no leak of refrigerant is observed (systems are generally tested with reference to their wet seal)
  - Verify through the liquid-gauge that the refrigerant charge is appropriate
  - Regulate the condensing pressure control system
  - Regulate the expansion valve properly, after you have completely opened the valve that controls the compressor's carter pressure
  - Regulation of the above control valve can only be done during defrost cycle
  - Regulate high and low pressure valves
  - Verify that water does not leak from the insulated pipes or from the joints

### 4.2. SET INTO OPERATION

In order to set the unit into operation please operate on the following buttons:


- Main switch
- ON-OFF button on the control panel (**pic.4.1**).
- Light button on the control panel
- Electronic control, on the control panel, for temperature setting.

**pic.4.1**



### 4.3. ELECTRONIC CONTROLLER

Refer to **pic. 4.2**



**pic.4.2**

#### ➤ ON-OFF FUNCTION.

Press the ON-OFF button (9) for 3 seconds to turn on or to turn off the display cabinet;

After the start of the display cabinet , the electronic controller is working when the temperature is displayed.

After a power failure , the electronic controller will again work as before.

#### ➤ HOW TO LOCK-UNLOCK THE KEYBOARD.

Press together the buttons (5) and (12) for more 3 seconds for locking the keyboard : the "POF" message will be displayed. It is only possible to see the temperature displayed. Press together the buttons (5) and (12) for more 3 seconds for unlocking the keyboard : the "POn" message will be displayed.

#### ➤ HOW TO SWITCH ON-OFF THE LIGHT.

Press the button (7).

#### ➤ HOW TO SEE AND MODIFY THE SET POINT.

Press and immediately release the button "SET"(11). The SET led starts blinking. To change the Set value press the buttons (5) or (12) within 10 seconds. To memorize the new set point value press the button "SET"(11).

#### ➤ HOW TO START A MANUAL DEFROSTING.

Press the button (6) for more than 2 seconds. The programmed interval to the next defrosting cycle will be automatically reset. Due a power failure during a manual defrosting cycle , this cycle will be breached and the programmed interval to the next defrosting cycle will be automatically reset.

#### ➤ BUTTON (8).

In the present electronic controller the button (8) is disabled.

## ➤ HOW TO SEE AND MODIFY THE PARAMETERS VALUES.

- Press the button (12) and at the same time press the button “SET”(11) for 3 seconds : the “HY” flashing message will be displayed.
- Press the button (5) to reach the message “PR2”.
- Press the button “SET”(11), “0 - -“ will be displayed with “0” flashing , after input the password “321” as follows.
- Press the button (5) three times to reach “3” and confirm with the button “SET”(11) ; “0” will be displayed flashing.
- Press the button (5) two times to reach “2” and confirm with the button “SET”(11) ; “0” will be displayed flashing.
- Press the button (5) one time to reach “1” and confirm with the button “SET”(11) .
- Now it is possible to see and/or modify the parameters values.
- Remember to press the button “SET”(11) to memorize the new values.
- Wait a few seconds without pressing any button.

## ➤ HOW TO SEE THE PROBES VALUES.

- Enter in “PR2” level.
- Select “Prd” parameter and press the button “SET”(11) to display “Pb1” label alternate with Pb1 value.
- Use the buttons (5) and (12) to display the other probes values.

## ➤ ALARMS.


Message	Cause	Outputs	
“P1”	Thermostat probe failure	Compressor output according to parameters “Con” and “Cof”	The alarm message is displayed until the alarm condition is recovery.
“P2”	Evaporator probe failure	Unchanged , only message	All the alarm messages are showed alternating with the cabinet temperature except for the “P1” which is flashing.
“P3”	Auxiliary probe failure	Unchanged , only message	
“HA”	Maximum temperature alarm	Unchanged , only message	
“LA”	Minimum temperature alarm	Unchanged , only message	
“EE”	Data or memory failure	Unchanged , only message	To reset the “EE” alarm and restart the normal functioning press any key ; the “Rst” message is displayed for about 3 seconds.
“dA”	Defrost timeout alarm	Unchanged , only message	
“EAL”	External alarm	Unchanged , only message	
“BAL”	Serious external alarm	Other outputs OFF	
“PAL”	Pressure switch alarm	Other outputs OFF	

## ALARM RECOVERY

- Probe alarms “P1” , “P2” and “P3” automatically stop 10 seconds after the probe restarts normal operation; check connections before replacing the probe.
- Temperature alarms “HA” and “LA” automatically stop as soon as the thermostat temperature returns to normal values or when the defrost starts.

## 4.4. PRODUCT LOADING

- Before loading the product inside the display cabinet, wait until the unit reaches the pre-set temperature and the compressor starts its cycle.
- Load the product only if it already has the correct storage temperature.
- Always check that the cold air inlet and outlet are not completely or partially obstructed by the product.
- The product doesn't exceed the load limit represented in **Pic.4.3 (10cm above the pan frame)**



## 4.5. SUGGESTED TEMPERATURES

The average storage temperatures for each kind of the refrigerated products are the following :

- |                              |              |
|------------------------------|--------------|
| - Ice cream                  | -13 ÷ -18 °C |
| - Granita                    | -8 ÷ -12 °C  |
| - Cake, industrial ice cream | -20 ÷ -22 °C |

## 4.6. AUTOMATIC DEFROSTING

The present refrigerated display cabinet has an automatic defrosting to eliminate the ice and snow on the evaporator.

All the parameters are pre-set by the customer , nevertheless their values can be changed by qualified technical personnel to adapt the working of the display cabinet to the particular ambient conditions. **RECOMMEND CASE BE TURNED OFF ONCE A WEEK FOR A OVERNIGHT DEFROST (10-12HRS).**

## 4.7. USE OF THE CURTAIN AND THE SLIDING PANELS

In order to guarantee the correct working of the display cabinet and whenever the sales allows it, the curtain must always be rolled down or , if present, the sliding panels must be closed.


## 4.8. STOPPING THE UNIT

If you wish to stop the display cabinet use the main switch that simultaneously will stop the display cabinet , the condensing unit and the control panel.

## 5. ROUTINE MAINTENANCE AND PERIODIC CHECKS

- These kinds of operations are at client's expenses.
- In case some malfunctioning of the unit are observed, please make sure this is not due to non-maintenance reasons, before you apply to qualified assistance.
- The accurate and periodic cleaning of the unit will reduce the risk of damages to the unit itself and to the products stored within.
- See following tab for reference.

**ATTENTION !** Before starting any maintenance and cleaning operation make sure you operate on the main switch in order to deactivate tension (pic. 5)



(pic 5)

### MAINTENANCE OPERATIONS AND THEIR FREQUENCY. A SUMMARY TAB.

OPERATION	DESCRIPTION	FREQUENCY
Surfaces' cleaning	<ul style="list-style-type: none"> <li>• Wash exclusively with warm water and neutral soap; rinse abundantly and wipe off with a soft cloth.</li> <li>• Do not use abrasive products</li> </ul>	weekly
Plastic surfaces' cleaning	<ul style="list-style-type: none"> <li>• Wash exclusively with warm water and neutral soap; rinse abundantly and wipe off with a soft cloth.</li> <li>• Do not use alcohol, acetone and any solvent that might spoil the look and structure of the material.</li> </ul>	weekly
Glass surfaces' cleaning	<ul style="list-style-type: none"> <li>• Use only specific products for glass cleaning</li> <li>• Using water alone might lead to calcareous deposits on the glass surfaces</li> </ul>	daily
Wooden surfaces' cleaning	<ul style="list-style-type: none"> <li>• Use exclusively a wet cloth.</li> </ul>	weekly
Additional defrost	<ul style="list-style-type: none"> <li>• Under particular conditions of temperature and humidity, the frost that normally forms on the evaporator and fans might increase in volume, so leading to a faulty functioning of the unit.</li> <li>• If these conditions should last, the assistance of a qualified technician shall be needed. Waiting for this service, it is suggested to operate one or more defrost cycles (despite the damages this might cause to the stored product)</li> </ul>	Waiting for qualified assistance
Periodic defrost	<ul style="list-style-type: none"> <li>• In order to obtain the best performance from the cooling system, we suggest to operate an extended defrost cycle.</li> <li>• Before you do that, please remove displayed products from inside the cabinet; always operate an additional defrost cycle in order to remove from the evaporator the largest possible amount of frost or ice. Turn the main switch off for 5 hours (min.)</li> <li>• Before re-starting the unit, make sure that frost has totally melted and wipe carefully.</li> </ul>	max. 15 DAYS


**ATTENTION! DO NOT CLEAN THE UNIT WITH WATER JETS**

## 6. EXTRAORDINARY MAINTENANCE

This type of operation has to be made by qualified technician only.

**ATTENTION!** Before operating any maintenance, make sure the tension is deactivated. (pic.11).

- Lamps' replacement: qualified technician needed.
- Air condenser cleaning: qualified technician needed. When the fan is switched off you can clean the condenser with a compressed air jet. Never use metallic brushes. Use protection gloves (pic.6).



(Pic.6.)


## 7. DEFECTS AND REMEDIES

DEFECT	PROBABLE CAUSES	POSSIBLE REMEDIES
The unit does not work	Automatic switch released due to absorption overload	Re-start the automatic switch
	Main switch off	Turn the main switch on
	Refrigeration switch off	Turn the refrigeration switch on
	Electrical black-out in the building	If the black-out does not end in a reasonable time frame, it become necessary to move the displayed product in another refrigerator
The temperature inside the display area does not get enough cold	The evaporator(s) is blocked by ice forming	Operate a complete defrost cycle after having displaced the products in another refrigerator. Do not put the product back in the cabinet until the real defect has been identified
	The internal fans are damaged or not working	Replace the damaged fans. If the fans are not damaged, an electrical defect must be identified. If the fans are replaced, the blades' inclination have to be maintained unchanged
	Excess of internal ventilation	Replace the fans and make sure that blades' inclination is kept unchanged
	The pre-set temperature of the digital control panel is wrong	Set the correct temperature
	The digital control is not working	Replace the slave module or the temperature sensor, after you made clear which one is faulty
	The display area is crossed by draught or exposed to direct/reflected sunbeams	Eliminate draughts and try to avoid sunbeams interference in any way
	Air condenser is clogged by dust or dirt	Clean the condenser with accuracy
	The cooling air flow of the condenser is not sufficient	Remove everything that might obstacle the air flow through the condenser
	Refrigerant gas not sufficient inside the cooling system	Find and remove the leak inside the system. Refill the system with the refrigerant
	The cooling water flow of the water condenser is not sufficient	Check that water supply is operating. In case it is, just regulate (or replace) the regulation valve
The product gets too hard next to air outlet and too soft next to air intake	Front evaporator blocked by frost	Verify the efficiency of the gasket seal (relatively to the glass superstructure). Verify that the display area is not crossed by draughts. Verify that backsliders (or night blind) are always closed, peak hours excepted. Verify that internal ventilation is sufficient and that the product does not exceed 10mm above the pans level. Act accordingly
	Front evaporator blocked by ice	All the a.m. checks are required Verify, in addition, the defrost cycle efficiency
	Back evaporator blocked by ice	Verify that the refrigerating and electric systems of the unit are working properly
	Internal fans are not efficient	Restore the efficiency of the fans by replacing the damaged ones
	The basket seal of the glass superstructure is not sufficient	Verify the seriousness of the defect and make sure the draughts are minimized
Some of the products tend to soften, while some other keep the right consistence	The temperature inside the display area is not fit for the products that get too soft	Since the storage temperature cannot be appropriate for any gelato product, based on different flavours and compositions, it is suggested to display only similar products together
The compressor does not start or it does not hold operating	There is no electrical supply	Verify there is no black-out in progress. Turn all the power switches on.
	The supply tension is too low	Verify that nominal tension at connecting clamps is 220V; a tension between 198V and 242V will be acceptable. If the tension does not reach 198V, the compressor might have problems in starting. Verify the efficiency of electric installation including the connecting clamps to the compressor
	The pre-set temperature on the thermostat is too high	If the preset temperature is higher than in the display area, the compressor is not going to work. Change the settings if you verify that the preset temperature is not enough low
	The intervention of the max pressure valve (where present)	Identify the probable cause among the following: The air condenser is blocked - The cooling fan of the air condenser is not working - The room temperature is too high - Lack of cooling water in the water condenser - The pressure valve is broken - Remove the cause

DEFECT	PROBABLE CAUSES	POSSIBLE REMEDIES
The compressor works constantly or for too long periods	The temperature inside the room is too high	The compressor can only work constantly if there is no chance of decreasing room temperature (for instance with a.c. system)
	The temperature of the compressors' room is too high (remote comp.)	See above
	The air condenser is blocked	Clean the condenser carefully
	Cooling air flow of the water condenser is not sufficient	Check the efficiency of the regulation valve and make sure that taps are turned on
	Lack of refrigerant	Identify the eventual leak and refill with refrigerant
	Internal ventilation is not sufficient	Restore a proper ventilation by replacing the faulty fans or by removing the eventual obstacle
	Evaporators are extremely clogged	Operate a complete defrost cycle
	The temperature set on the thermostat is too low	Adjust temperature settings
Temperature is not displayed on the digital panel	Flat battery	Replace battery
	Sensor does not work properly	Replace digital thermostat
	Faulty electronics	Replace digital thermostat
Defrost water missing	Water drain pipes are blocked	Remove the obstacle
	Defrost cycle is not efficient	Verify the efficiency of control panel (slave module, sensor, solenoid valve..) and the position of the end cycle sensor
Lighting is not working	The switch is off	Turn the switch on
	The neon lamp is not properly fitted in its case	Ad just the lamp by rolling it
	Exhausted lamp	Replace the lamp
	Ballasts or starter are not efficient	Replace faulty components
The unit is too noisy	Vibrations of internal plates	Tighten all the fixing screws
	Internal fans are not fixed well	See above
	Fans' blades are not fixed well	Replace faulty fans. If there is friction between the blades and some ice formation, then act on defrost cycle settings
	Pipes are in contact with other parts of equipment	Avoid any contact between pipes and other parts; a constant rubbing might wear the pipes out and give way to refrigerant leaking
	The unit is not well levelled	Adjust the levelling
Condensation water forming on the glasses	Transformer is not working	Check that the transformer is correctly supplied - Verify the correct functioning of the transformer fuse - Replace the transformer
	Heating circuit interrupted	Replace the glasses

## REFRIGERATION AND ELECTRICAL SYSTEM CABLE CONNECTION GUIDE

<b>AGD</b>	DIGITAL FLAVOURS DISPLAY FEEDER	<b>RES28</b>	FRONT GLASS LOWER FRAME HEATING ELEMENT
<b>AEL</b>	ELECTRONIC BALLAST	<b>RES29</b>	FRONT GLASSES COUPLING PROFILE HEATING ELEMENT
<b>AP</b>	SERVICE VALVE	<b>RES30</b>	DOORS FRAME MIDDLE POST HEATING ELEMENT
<b>CA</b>	SUPPLY CABLE	<b>RES31</b>	GLASSES PERIMETRAL FRAME HEATING ELEMENT
<b>CAR</b>	AIR CONDENSER	<b>RES32</b>	HEATED DOORS HEATING ELEMENTS
<b>CE</b>	ELECTRONIC CONTROL	<b>RES33</b>	WATER DRAIN HEATING ELEMENT
<b>CN</b>	MULTIPOLAR CONNECTOR	<b>RES34</b>	DOORS FRAME HEATING ELEMENT
<b>CO</b>	COMPRESSOR	<b>RES35</b>	COMPRESSOR CRANKCASE HEATING ELEMENT
<b>D</b>	DIOD	<b>RES36</b>	FRONT GLASS FRAME HEATING ELEMENT
<b>DEV</b>	SHUNT	<b>RES37</b>	CABINET FRAME HEATING ELEMENT
<b>DR</b>	REMOTE DISPLAY	<b>RES38</b>	HOT COMPARTMENT HEATING ELEMENT
<b>EM</b>	PHOTOCELL Emitter	<b>REV</b>	CONDENSER FAN SPEED CONTROL
<b>EV</b>	EVAPORATOR	<b>REVC</b>	CONDENSER FAN RELAY
<b>F</b>	FUSE	<b>RI</b>	REFRIGERANT TAP
<b>FD</b>	FILTER DRIER	<b>RIC</b>	COMPRESSOR DELAYER
<b>FLU</b>	WATER FLOW SWITCH	<b>RICV</b>	PHOTOCELL RECEIVER
<b>FR</b>	COMPRESSOR THERMAL PROTECTION	<b>RIS</b>	RESERVE , ANTI-FOG HEATER ELEMENT
<b>HL</b>	COMPRESSOR ALARM LIGHT	<b>RL</b>	LIQUID RECEIVER
<b>I</b>	GENERIC SWITCH	<b>RLA</b>	WATER LEVEL ELECTRONIC CONTROL
<b>IEC</b>	WATER EVAPORATION BIN SWITCH	<b>RO</b>	OIL HEATER ELEMENT
<b>IGD</b>	DIGITAL FLAVOURS DISPLAY	<b>SAA</b>	ABSENCE OF WATER LIGHT
<b>II</b>	LIGHTING SWITCH	<b>SC</b>	CONDENSER PROBE
<b>IL</b>	SIGHT GLASS	<b>SD</b>	TERMINAL BOX
<b>IMC</b>	WARM SHELF SWITCH	<b>SDC</b>	COMPRESSOR TERMINAL BOX
<b>INV</b>	INVERTER	<b>SE</b>	PROXIMITY SENSOR
<b>IR</b>	REFRIGERATION SWITCH	<b>SEC</b>	MAIN SWITCH
<b>IRP</b>	LIGHT REFRIGERATION SWITCH	<b>SFV</b>	TANK BOTTOM HEATING COIL
<b>IV</b>	INTERNAL FAN SWITCH	<b>SIDG</b>	FLAVOURS DISPLAY DIGITAL SYSTEM
<b>KM</b>	CONTACTOR	<b>SL</b>	LIQUID SEPARATOR
<b>LF</b>	FRONT LIGHTING	<b>SLA</b>	WATER LEVER PROBE
<b>LI</b>	INTERNAL UPPER LIGHTING	<b>SPC</b>	COMPRESSOR LIGHT
<b>LIA</b>	FRONT LIGHTING	<b>SPMC</b>	WARM SHELF LIGHT
<b>LIG</b>	FLAVOURS DISPLAY LIGHTING	<b>SPR</b>	ELECTRIC SUPPLY LIGHT
<b>LIP</b>	REAR LIGHTING	<b>SPS</b>	DEFROSTING LIGHT
<b>MDIG</b>	DIGITAL MODULE FOR FLAVOURS DISPLAY	<b>SS</b>	DEFROSTING PROBE
<b>MM</b>	SPINNING SHELVES ELECTRIC MOTOR	<b>ST</b>	TEMPERATURE PROBE
<b>MUC</b>	CONDENSING UNIT ELECTRIC CONNECTIONS	<b>STR</b>	LIGHTING STARTER
<b>PA</b>	HIGH PRESSURE CONTROL	<b>SU</b>	HUMIDITY PROBE
<b>PD</b>	HIGH-LOW PRESSURE CONTROL	<b>T</b>	TEMPERATURE CONTROL
<b>PO</b>	WATER PUMP	<b>TI</b>	WINTER THERMOSTAT
<b>QE</b>	EXTERNAL ELECTRIC PANEL	<b>TC</b>	CAPILLARY TUBE
<b>QF</b>	MAGNETIC-THERMIC SWITCH	<b>TE</b>	TIMER
<b>R</b>	LIGHTING BALLAST	<b>TER</b>	THERMOMETER
<b>RADD</b>	RECTIFIER	<b>TF</b>	FUSIBLE PLUG
<b>RE</b>	GENERIC RELAY	<b>TMC</b>	WARM SHELF THERMOSTAT
<b>REL</b>	ELECTRONIC BALLAST	<b>TP</b>	LIGHTING FIXTURES REGRIGERATOR THERMOSTAT
<b>REP</b>	ELECTRONIC CONTROL TEMPERATURE REPEATER	<b>TRA</b>	TRANSFORMER
<b>RES1</b>	COLD AIR DISCHARGE HEATING ELEMENT	<b>TRC</b>	ELECTRONIC CONTROL TRANSFORMER
<b>RES2</b>	FRONT PROFILE HEATING ELEMENT	<b>TREV</b>	WATER EVAPORATION HEATER ELEMENT THERMOSTAT
<b>RES3</b>	RIGHT/LEFT GLASS HEATING ELEMENT	<b>TS</b>	SECURITY THERMOSTAT
<b>RES4</b>	FRONT GLASS HEATING ELEMENT	<b>TVC</b>	CONDENSER FAN THERMOSTAT
<b>RES5</b>	DEFROST HEATING ELEMENT	<b>V</b>	COMPRESSOR FAN / GENERAL USE
<b>RES6</b>	WATER EVAPORATION HATING ELEMENT	<b>VC</b>	CONDENSER FAN
<b>RES7</b>	TOP LIGHTING FIXTURE HEATING ELEMENT	<b>VES</b>	WATER EVAPORATION BIN
<b>RES8</b>	LATERAL GLASS SUPPORT HEATING ELEMENT	<b>VI</b>	EXPANSION VALVE
<b>RES9</b>	FRONT BAND HEATING ELEMENT	<b>VPA</b>	INTERNAL FAN
<b>RES10</b>	COUPLING BAND HEATING ELEMENT	<b>VR</b>	CONDENSING PRESSURE CONTROL WATER VALVE
<b>RES11</b>	SERVICE TOP HEATING ELEMENT	<b>VRA</b>	CHECK VALVE
<b>RES12</b>	UPPER BAND/DOOR FRAME HEATING ELEMENT	<b>VRE</b>	SUCTION PRESSURE REGULATION VALVE
<b>RES13</b>	HOT DRY/BAIN MARIE DISPLAY HEATING ELEMENT	<b>VS</b>	EVAPOTATING PRESSURE REGUTATION VALVE
<b>RES14</b>	ANTI-FOG SUCTION AIR BAND HEATING ELEMENT	<b>VSA</b>	GENERAL USE SOLENOID VALVE
<b>RES15</b>	WARM SHELF HEATING ELEMENT	<b>VSAB</b>	SOLENOID WATER VALVE
<b>RES16</b>	SIDE BANDS/ FRONT GLASS HINGE HEATING ELEMENT	<b>VSIC</b>	BY-PASS SOLENOID WATER VALVE
<b>RES17</b>	DEHUMIDIFICATION HEATING ELEMENT	<b>VSL</b>	REVERSING CYCLE SOLENOID VALVE
<b>RES18</b>	DEFROSTING WATER DRAIN HEATING ELEMENT	<b>VSS</b>	LIQUID SOLENOID VALVE
<b>RES19</b>	RING FRAME HEATING ELEMENT	<b>VT</b>	DEFROSTING SOLENOID VALVE
<b>RES20</b>	SIDE BAND HEATING ELEMENT	<b>VV</b>	POWER REGULATOR
<b>RES21</b>	SUCTION AIR GLASS HEATING ELEMENT	<b>X1</b>	GLASS FAN
<b>RES22</b>	OUTLET AIR HEATING ELEMENT	<b>X2</b>	CABINET CONNECTIONS
<b>RES23</b>	REAR GLASS HEATING ELEMENT	<b>X3</b>	EXTERNAL ELECTRIC PANEL CONNECTIONS
<b>RES24</b>	INTERNAL GLASS HEATING ELEMENT		CONDENSING UNIT CONNECTIONS
<b>RES25</b>	FRONT GLASS UPPER FRAME HEATING ELEMENT		
<b>RES26</b>	FRONT GLASS LATERAL/LOWER FRAME HEATING ELEMENT		
<b>RES27</b>	FRONT GLASS LATERAL FRAME HEATING ELEMENT		



WING

## XW270L - XW271L

## 1. GENERAL WARNING



## 1.1 PLEASE READ BEFORE USING THIS MANUAL

- This manual is part of the product and should be kept near the instrument for easy and quick reference.
- The instrument shall not be used for purposes different from those described hereunder. It cannot be used as a safety device.
- Check the application limits before proceeding.



## 1.2 SAFETY PRECAUTIONS

- Check the supply voltage is correct before connecting the instrument.
- Do not expose to water or moisture: use the controller only within the operating limits avoiding sudden temperature changes with high atmospheric humidity to prevent formation of condensation
- Warning: disconnect all electrical connections before any kind of maintenance.
- Fit the probe where it is not accessible by the End User. The instrument must not be opened.
- In case of failure or faulty operation send the instrument back to the distributor or to "Dixell s.r.l." (see address) with a detailed description of the fault.
- Consider the maximum current which can be applied to each relay (see Technical Data).
- Ensure that the wires for probes, loads and the power supply are separated and far enough from each other, without crossing or intertwining.
- In case of applications in industrial environments, the use of mains filters (our mod. FT1) in parallel with inductive loads could be useful.

## 2. GENERAL DESCRIPTION

Models XW270L and XW271L, 38x185 mm format, are microprocessor based controllers suitable for applications on medium or low temperature refrigerating units. They are provided with six relay outputs to control compressor, defrost - which can be either electrical or hot gas - the evaporator fans, the lights, the alarm and an auxiliary output. In XW271L the auxiliary output is configured as anti-condensing heater. They are also provided with three NTC probe inputs, one for temperature control, one to control the defrost end temperature of the evaporator and the third, optional, for the display. There are two digital inputs (free contact) for the door switch and configurable by parameter.

The standard TTL output allows the user to connect, by means of a TTL/RS485 external module, a ModBUS-RTU compatible monitoring system and to programme the parameter list with the "Hot Key". An optional output for remote display "XW-REP" is available.

## 3. CONTROLLING LOADS

## 3.1 THE COMPRESSOR

The regulation is performed according to the temperature measured by the thermostat probe with a positive differential from the set point: if the temperature increases and reaches set point plus differential the compressor is started and then turned off when the temperature reaches the set point value again.

In case of fault in the thermostat probe the start and stop of the compressor are timed through parameters "COn" and "COF".

## 3.2 FAST FREEZING

When defrost is not in progress, it can be activated the keypad by holding the  $\Delta$  key pressed for about 3 seconds. The compressor operates in continuous mode for the time set through the "CC1" parameter. The cycle can be terminated before the end of the set time using the same activation key,  $\Delta$  for about 3 seconds.

## 3.3 DEFROST

Three defrost modes are available through the "IdF" parameter: defrost with electrical heater, hot gas or thermostatic defrost. The defrost interval is control by means of parameter "EdF": (EdF=in) the defrost is made every "IdF" time, (EdF=Sd) the interval "IdF" is calculate through Smart Defrost algorithm (only when the compressor is ON and the evaporator temperature is bigger than "SdF" parameter). At the end of defrost the drip time is controlled through the "FdF" parameter.

## 3.4 CONTROL OF EVAPORATOR FANS

The fan control mode is selected by means of the "FnC" parameter:

FnC=C-n fans will switch ON and OFF with the compressor and **not run** during defrost;

FnC=C-y fans will run continuously, but not during defrost

After defrost, there is a timed fan delay allowing for drip time, set by means of the "FdF" parameter.

FnC=O-n fans will switch ON and OFF with the compressor and **run** during defrost;

FnC=O-y fans will run continuously also during defrost

An additional parameter "FSI" provides the setting of temperature, detected by the evaporator probe, above which the fans are always OFF. This can be used to make sure circulation of air only if its temperature is lower than set in "FSI".

## 3.5 AUXILIARY OUTPUT

The auxiliary output is switch ON and OFF by means of the corresponding button on the keyboard. The auxiliary output of the XW271L model controls the anti-condensing heater and it is automatically activated if the room temperature is lower than the "SAA" parameter.

## 4. KEYBOARD



To display and modify target set point; in programming mode it selects a parameter or confirm an operation.

By holding it pressed for 3s when max or min temperature is displayed it will be erased.

To see the max. stored temperature; in programming mode it browses the parameter codes or increases the displayed value. By holding it pressed for 3s the fast freezing cycle is started.

To see the min stored temperature; in programming mode it browses the parameter codes or decreases the displayed value.

By holding it pressed for 3s the defrost is started.

Switch ON and OFF the cold room light.

By holding it pressed for 3s Energy Saving function is started or stopped.

aux For XW270L model. Switch ON and OFF the auxiliary output.

For XW271L model. Switch ON and OFF the anti-condensing heater output.

Switch ON and OFF the instrument.

## KEY COMBINATIONS

+ To lock and unlock the keyboard.

+ To enter the programming mode.

+ To exit the programming mode.

## 4.1 USE OF LEDS

Each LED function is described in the following table.

LED	MODE	Function
	ON	The compressor is running
	FLASHING	- Programming Phase (flashing with LED ) - Anti-short cycle delay enabled
	ON	The fan is running
	FLASHING	Programming Phase (flashing with LED )
	ON	The defrost is enabled
	FLASHING	Drip time in progress
	ON	The Fast Freezing cycle is enabled
	ON	- ALARM signal - In "Pr2" indicates that the parameter is also present in "Pr1"
	ON	(Present only in XW271L) The Anti-condensing heater relay (Aux) is ON.

Function of the LEDs placed on the left top side of buttons:

BUTTON	MODE	FUNCTION
SET	FLASHING	The Set point is displayed and it can be modified
SET	FAST FLASHING	The Energy Saving is enabled
DEFROST	ON	The Manual Defrost is activated
ENERGY SAVING	ON	The Energy Saving is enabled
LIGHT	ON	The Light is ON
AUX	ON	The Auxiliary output is ON (XW270L)
HEATER	ON	The Anti-condensing heater is ON (XW271L)
ON/OFF	ON	The instrument is OFF

## 4.2 HOW TO SEE THE MIN TEMPERATURE

- Press and release the  $\Delta$  key.
- The "Lo" message will be displayed followed by the minimum temperature recorded.
- By pressing the  $\Delta$  key or waiting for 5s the normal display will be restored.

## 4.3 HOW TO SEE THE MAX TEMPERATURE

- Press and release the  $\Delta$  key.
- The "Hi" message will be displayed followed by the maximum temperature recorded.
- By pressing the  $\Delta$  key or waiting for 5s the normal display will be restored.

## 4.4 HOW TO RESET THE MAX AND MIN TEMPERATURE RECORDED

To reset the stored temperature, when max or min temperature is displayed :

- Press SET key until "ST" label starts blinking.

N.B. After the installation RESET the temperature stored .

## HOW TO SEE AND MODIFY THE SET POINT

- Push and immediately release the SET key: the display will show the Set point value;
- The SET LED start blinking;
- To change the Set value push the  $\Delta$  or  $\Delta$  arrows within 10s.
- To memorise the new set point value push the SET key again or wait 10s.

**TO START A MANUAL DEFROST**

- Push the DEF key for more than 2 seconds and a manual defrost will start.

**TO ENTER IN PARAMETERS LIST "PR1"**

To enter the parameter list "Pr1" (user accessible parameters) operate as follows:



- Enter the Programming mode by pressing the Set and DOWN key for few seconds ( and start blinking).
- The instrument will show the first parameter present in "Pr1"

**TO ENTER IN PARAMETERS LIST "PR2"**

To access parameters in "Pr2":

- Enter the "Pr1" level.
- Select "Pr2" parameter and press the "SET" key.
- The "PAS" flashing message is displayed, shortly followed by "0 - -" with a flashing zero.
- Use  $\Delta$  or  $\nabla$  to input the security code in the flashing digit; confirm the figure by pressing "SET". The security code is "321".
- If the security code is correct the access to "Pr2" is enabled by pressing "SET" on the last digit.

Another possibility is the following: after switching ON the instrument the user can push Set and DOWN keys within 30 seconds.

**NOTE:** each parameter in "Pr2" can be removed or put into "Pr1" (user level) by pressing "SET" +  $\nabla$ . When a parameter is present in "Pr1" LED ( is on.

**HOW TO CHANGE THE PARAMETER VALUE**

- Enter the Programming mode.
- Select the required parameter with  $\Delta$  or  $\nabla$ .
- Press the "SET" key to display its value ( and LED starts blinking).
- Use  $\Delta$  or  $\nabla$  to change its value.
- Press "SET" to store the new value and move to the following parameter.

**To exit:** Press SET + UP or wait 15s without pressing a key.

**NOTE:** the new programming is stored even when the procedure is exited by waiting the time-out.

**HOW TO LOCK THE KEYBOARD**

- Keep the  $\Delta$  and  $\nabla$  keys pressed together for more than 3 s the  $\Delta$  and  $\nabla$  keys.
- The "POF" message will be displayed and the keyboard is locked. At this point it is only possible the viewing of the set point or the MAX o Min temperature stored and to switch ON and OFF the light, the auxiliary output and the instrument.

**TO UNLOCK THE KEYBOARD**

Keep the  $\Delta$  and  $\nabla$  keys pressed together for more than 3s.

**ON/OFF FUNCTION**

By pushing the ON/OFF key, the instrument shows "OFF" for 5 sec. and the ON/OFF LED is switched ON.

During the OFF status, all the relays are switched OFF and the regulations are stopped; if a monitoring system is connected, it does not record the instrument data and alarms.

**N.B.** During the OFF status the Light and AUX buttons are active.

**TO SEE THE PROBE VALUES**

- Enter in "Pr2" level.
- Select "Prd" parameter with  $\Delta$  or  $\nabla$ .
- Press the "SET" key to display "Pb1" label alternate with Pb1 value.
- Use  $\Delta$  and  $\nabla$  keys to display the other probe values.
- Press "SET" to move to the following parameter.

**PARAMETER LIST****REGULATION**

- Hy** Differential: (0,1÷25,5°C; 1÷45°F): Intervention differential for set point, always positive. Compressor Cut IN is Set Point Plus Differential (Hy). Compressor Cut OUT is when the temperature reaches the set point.
- LS** Minimum set point limit: (-50,0°C+SET; -58°F+SET) Sets the minimum acceptable value for the set point.
- US** Maximum set point limit: (SET+110°C; SET+230°F) Set the maximum acceptable value for set point.
- Ods** Outputs activation delay at start up: (0÷255 min) This function is enabled at the initial start up of the instrument and inhibits any output activation for the period of time set in the parameter. (AUX and Light can work)
- AC** Anti-short cycle delay: (0÷30 min) interval between the compressor stop and the following restart.
- CCT** Thermostat override: (0min ÷ 23h 50min) allows to set the length of the continuous cycle. Can be used, for instance, when the room is filled with new products.
- Con** Compressor ON time with faulty probe: (0÷255 min) time during which the compressor is active in case of faulty thermostat probe. With COn=0 compressor is always OFF.
- COF** Compressor OFF time with faulty probe: (0÷255 min) time during which the compressor is off in case of faulty thermostat probe. With COF=0 compressor is always active.

**DISPLAY**

**CF** Temperature measurement unit: °C = Celsius; °F = Fahrenheit . When the measurement unit is changed the SET point and the values of the regulation parameters have to be modified

**rES** Resolution (for °C): (in = 1°C; de = 0,1°C) allows decimal point display.

de = 0,1°C

in = 1 °C

**Lod** Local display : select which probe is displayed by the instrument:

P1 = Thermostat probe

P2 = Evaporator probe

P3 = auxiliary probe

1r2 = difference between P1 and P2 (P1-P2)

**Red** Remote display : select which probe is displayed by the remote display (XW-REP)

P1 = Thermostat probe

P2 = Evaporator probe

P3 = auxiliary probe

1r2 = difference between P1 and P2 (P1-P2)

**DEFROST**

**tdF** Defrost type:

rE = electrical heater (Compressor OFF)

rT = thermostat defrost. During the defrost time "MdF", the heater switches On and OFF depending on the evaporator temperature and "diE" value.

in = hot gas (Compressor and defrost relays ON)

**EdF** Defrost mode:

in = interval mode. The defrost starts when the time "IdF" is expired.

Sd = Smartfrost mode. The time IdF (interval between defrosts) is increased only when the compressor is running (even non consecutively) and only if the evaporator temperature is less than the value in "SdF" (set point for SMARTFROST).

**SdF** Set point for SMARTFROST: (-30÷30 °C / -22÷86 °F) evaporator temperature which allows the IdF counting (interval between defrosts) in SMARTFROST mode.

**dTE** Defrost termination temperature: (-50,0÷110,0°C; -58÷230°F) (Enabled only when the evaporator probe is present) sets the temperature measured by the evaporator probe which causes the end of defrost.

**IdF** Interval between defrosts: (1÷120h) Determines the time interval between the beginning of two defrost cycles.

**MdF** (Maximum) duration of defrost: (0÷255 min) When P2P = n, no evaporator probe, it sets the defrost duration, when P2P = y, defrost end based on temperature, it sets the maximum length for defrost.

**dFd** Display during defrost:

rt = real temperature;

it = temperature reading at the defrost start;

Set = set point;

dEF = "dEF" label;

dEG = "dEG" label;

**dAd** Defrost display time out: (0÷255 min) Sets the maximum time between the end of defrost and the restarting of the real room temperature display.

**Fdt** Drain down time: (0÷60 min.) time interval between reaching defrost termination temperature and the restoring of the control's normal operation. This time allows the evaporator to eliminate water drops that might have formed due to defrost.

**dPO** First defrost after start-up:

y = Immediately;

n = after the IdF time

**dAF** Defrost delay after fast freezing: (0min÷23h 50min) after a Fast Freezing cycle, the first defrost will be delayed for this time.

**FANS**

**FnC** Fan operating mode:

C-n = running with the compressor, OFF during the defrost;

C-y = running with the compressor, ON during the defrost;

O-n = continuous mode, OFF during the defrost;

O-y = continuous mode, ON during the defrost;

**Fnd** Fan delay after defrost: (0÷255 min) The time interval between the defrost end and evaporator fans start.

**FSt** Fan stop temperature: (-50÷110°C; -58÷230°F) setting of temperature, detected by evaporator probe, above which the fan is always OFF.

**ALARMS**

**ALC** Temperature alarm configuration

rE = High and Low alarms related to Set Point

Ab = High and low alarms related to the absolute temperature.

**ALU** High temperature alarm setting:

ALC= rE, 0 + 50°C or 90°F

ALC= Ab, ALL + 110°C or 230°F

when this temperature is reached and after the ALd delay time the HA alarm is enabled.

**ALL** Low temperature alarm setting:

ALC = rE , 0 + 50 °C or 90°F

ALC = Ab , - 50°C or -58°F + ALU

when this temperature is reached and after the ALd delay time, the LA alarm is enabled.

**AFH** Temperature alarm and fan differential: (0,1÷25,5°C; 1÷45°F) Intervention differential for temperature alarm set point and fan regulation set point, always positive.

**ALd** Temperature alarm delay: (0÷255 min) time interval between the detection of an alarm condition and the corresponding alarm signalling.

**dAO** Delay of temperature alarm at start-up: (0min÷23h 50min) time interval between the detection of the temperature alarm condition after the instrument power on and the alarm signalling.

**EdA** Alarm delay at the end of defrost: (0÷255 min) Time interval between the detection of the temperature alarm condition at the end of defrost and the alarm signalling.

**dot** Delay of temperature alarm after closing the door : (0÷255 min) Time delay to signal the temperature alarm condition after closing the door.

**doA** Open door alarm delay:(0÷255 min) delay between the detection of the open door condition and its alarm signalling: the flashing message "dA" is displayed.

**tbA** Buzzer and alarm relay silencing: by pushing one of the keypad buttons.

n= Only the Buzzer is silenced;

y= Buzzer and relay are silenced.

**nPS** Pressure switch number: (0 +15) Number of activation of the pressure switch, during the "did" interval, before signalling the alarm event (I2F= PAL).

**PROBE INPUTS**

**Ot** Thermostat probe calibration: (-12.0÷12.0°C/ -21÷21°F) allows to adjust possible offset of the thermostat probe.

**OE** Evaporator probe calibration: (-12.0÷12.0°C/ -21÷21°F) allows to adjust possible offsets of the evaporator probe.

O3 **Auxiliary probe calibration:** (-12.0+12.0°C / -21+21°F) allows to adjust possible offsets of the evaporator probe.

P2P **Evaporator probe presence:**

n= not present: the defrost stops only by time; y= present: the defrost stops by temperature and time.

P3P **Auxiliary probe presence:** n= not present; y= present.

HES **Temperature increase during the Energy Saving cycle :** (-30,0°C + 30,0°C / -22+86°F) sets the increasing value of the set point during the Energy Saving cycle.

#### DIGITAL INPUTS

odc **Compressor and fan status when open door:**

no = normal;

Fan = Fan OFF;

CPr = Compressor OFF;

F\_C = Compressor and fan OFF.

I1P **Door switch input polarity:**

CL : the digital input is activated by closing the contact;

OP : the digital input is activated by opening the contact.

I2P **Configurable digital input polarity:**

CL : the digital input is activated by closing the contact;

OP : the digital input is activated by opening the contact

I2F **Digital input operating mode:** configure the digital input function:

EAL = generic alarm;

bal = serious alarm mode;

PAL = Pressure switch;

dFr = Start defrost;

AUS = Relay AUX actuation;

Es = Energy Saving;

onF = remote On/OFF.

did **Time interval/delay for digital input alarm:** (0+255 min.) Time interval to calculate the number of the pressure switch activation when I2F=PAL. If I2F=EAL or bal (external alarms), "did" parameter defines the time delay between the detection and the successive signalling of the alarm.

SAA **Set Point for anti-condensing heater:** (-50,0÷110,0°C; -58÷230°F) defines the room temperature setpoint to switch on the anti-condensing heater.

#### OTHER

Adr **RS485 serial address:** (1÷247): Identifies the instrument address when connected to a ModBUS compatible monitoring system.

Rel **Release software:** (read only) Software version of the microprocessor.

Ptb **Parameter table:** (read only) it shows the original code of the **dixell** parameter map.

Prd **Probes display:** (read only) display the temperature values of the evaporator probe Pb2 and the auxiliary probe Pb3.

Pr2 **Access to the protected parameter list:** (read only).

#### DIGITAL INPUTS

The Wing series can support up to 2 free contact digital inputs. One is always configured as door switch, the second is programmable in seven different configurations by the "I2F" parameter.

#### DOOR SWITCH INPUT

It signals the door status and the corresponding relay output status through the "odc" parameter:

no = normal (any change);

Fan = Fan OFF;

CPr = Compressor OFF;

F\_C = Compressor and fan OFF.

Since the door is opened, after the delay time set through parameter "dOA", the alarm output is enabled and the display shows the message "dA". The alarm stops as soon as the external digital input is disabled again. During this time and then for the delay "dot" after closing the door, the high and low temperature alarms are disabled.

#### CONFIGURABLE INPUT - GENERIC ALARM (EAL)

As soon as the digital input is activated the unit will wait for "did" time delay before signalling the "EAL" alarm message. The outputs status don't change. The alarm stops just after the digital input is de-activated.

#### CONFIGURABLE INPUT - SERIOUS ALARM MODE (BAL)

When the digital input is activated, the unit will wait for "did" delay before signalling the "BAL" alarm message. The relay outputs are switched OFF. The alarm will stop as soon as the digital input is de-activated.

#### CONFIGURABLE INPUT - PRESSURE SWITCH (PAL)

If during the interval time set by "did" parameter, the pressure switch has reached the number of activation of the "nPS" parameter, the "PAL" pressure alarm message will be displayed. The compressor and the regulation are stopped. When the digital input is ON the compressor is always OFF.

#### CONFIGURABLE INPUT - START DEFROST (DFR)

It executes a defrost if there are the right conditions. After the defrost is finished, the normal regulation will restart only if the digital input is disabled otherwise the instrument will wait until the "MdI" safety time is expired.

#### CONFIGURABLE INPUT - RELAY AUX ACTUATION (AUS)

This function allows to turn ON and OFF the auxiliary relay by using the digital input as external switch.

#### CONFIGURABLE INPUT - ENERGY SAVING (ES)

The Energy Saving function allows to change the set point value as the result of the SET+ HES (parameter) sum. This function is enabled until the digital input is activated.

#### CONFIGURABLE INPUT - REMOTE ON/OFF (ONF)

This function allows to switch ON and OFF the instrument.

#### DIGITAL INPUTS POLARITY

The digital inputs polarity depends on "I1P" and "I2P" parameters.


CL : the digital input is activated by closing the contact.

OP : the digital input is activated by opening the contact


#### INSTALLATION AND MOUNTING

Instruments **XW270L**, **XW271L** shall be mounted on vertical panel, in a 150x31 mm hole, and fixed using two screws Ø 3 x 2mm. To obtain an IP65 protection grade use the front panel rubber gasket (mod. RG-L). The temperature range allowed for correct operation is 0 - 60 °C. Avoid places subject to strong vibrations, corrosive gases, excessive dirt or humidity. The same recommendations apply to probes. Let the air circulate by the cooling holes.


#### CUT OUT



#### MOUNTING WITH KEYBOARD COVER OPENING DOWNWARD



#### MOUNTING WITH KEYBOARD COVER OPENING UPWARD



#### ELECTRICAL CONNECTIONS

The instruments are provided with screw terminal block to connect cables with a cross section up to 2,5 mm<sup>2</sup> for the digital and analogue inputs. Relays and power supply have a Faston connection (6,3mm). Heat-resistant cables have to be used. Before connecting cables make sure the power supply complies with the instrument's requirements. Separate the probe cables from the power supply cables, from the outputs and the power connections. Do not exceed the maximum current allowed on each relay, in case of heavier loads use a suitable external relay.

**N.B.** Maximum current allowed for all the loads is 20A.

#### PROBE CONNECTIONS

The probes shall be mounted with the bulb upwards to prevent damages due to casual liquid infiltration. It is recommended to place the thermostat probe away from air streams to correctly measure the average room temperature. Place the defrost termination probe among the evaporator fins in the coldest place, where most ice is formed, far from heaters or from the warmest place during defrost, to prevent premature defrost termination.

#### TTL SERIAL LINE

The TTL connector allows, by means of the external module TTL/RS485, to connect the unit to a network line **ModBUS-RTU** compatible as the **dixell** monitoring system XJ500 (Version 3.0).

The same TTL connector is used to upload and download the parameter list of the "HOT KEY".

**USE OF THE PROGRAMMING "HOT KEY"**

The Wing units can UPLOAD or DOWNLOAD the parameter list from its own E2 internal memory to the "Hot Key" and vice-versa.

**DOWNLOAD (FROM THE "HOT KEY" TO THE INSTRUMENT)**

- Turn OFF the instrument by means of the ON/OFF key, remove the TTL serial cable if present, insert the "Hot Key" and then turn the Wing ON.
- Automatically the parameter list of the "Hot Key" is downloaded into the Wing memory, the "DoL" message is blinking. After 10 seconds the instrument will restart working with the new parameters.
- Turn OFF the instrument remove the "Hot Key", plug in the TTL serial cable, then turn it ON again. At the end of the data transfer phase the instrument displays the following messages:  
"end" for right programming. The instrument starts regularly with the new programming.  
"err" for failed programming. In this case turn the unit off and then on if you want to restart the download again or remove the "Hot key" to abort the operation.

**UPLOAD (FROM THE INSTRUMENT TO THE "HOT KEY")**

- Turn OFF the instrument by means of the ON/OFF key and remove the TTL serial cable if present; then turn it ON again.
- When the Wing unit is ON, insert the "Hot key" and push **▲** key: the "uPL" message appears.
- Push "SET" key to start the UPLOAD; the "uPL" message is blinking.
- Turn OFF the instrument remove the "Hot Key", plug in the TTL serial cable, then turn it ON again. At the end of the data transfer phase the instrument displays the following messages:  
"end" for right programming.  
"err" for failed programming. In this case push "SET" key if you want to restart the programming again or remove the not programmed "Hot key".

**ALARM SIGNALS**

Message	Cause	Outputs
"P1"	Thermostat probe failure	Alarm output ON; Compressor output according to parameters "COn" and "COF"
"P2"	Evaporator probe failure	Alarm output ON; Other outputs unchanged
"P3"	Auxiliary probe failure	Alarm output ON; Other outputs unchanged
"HA"	Maximum temperature alarm	Alarm output ON; Other outputs unchanged
"LA"	Minimum temperature alarm	Alarm output ON; Other outputs unchanged
"EE"	Data or memory failure	Alarm output ON; Other outputs unchanged
"dA"	Defrost timeout alarm	Alarm output ON; Other outputs unchanged
"dAL"	Door switch alarm	Alarm output ON; Other outputs unchanged
"EAL"	External alarm	Alarm output ON; Other outputs unchanged
"BAL"	Serious external alarm	Alarm output ON; Other outputs OFF
"PAL"	Pressure switch alarm	Alarm output ON; Other outputs OFF

The alarm message is displayed until the alarm condition is recovered.

All the alarm messages are showed alternating with the room temperature except for the "P1" which is flashing. To reset the "EE" alarm and restart the normal functioning press any key. the "rSt" message is displayed for about 3s.

**SILENCING BUZZER / ALARM RELAY OUTPUT**

If "tbA = y", once the alarm signal is detected the buzzer and the relay are silenced by pressing any key.  
If "tbA = n", only the buzzer is silenced while the alarm relay is on until the alarm condition recovers.

**"EE" ALARM**

The **dixell** instruments are provided with an internal check for the data integrity. Alarm "EE" flashes when a failure in the memory data occurs. In such cases the alarm output is enabled.

**ALARM RECOVERY**

Probe alarms : "P1" (probe1 faulty), "P2" and "P3"; they automatically stop 10s after the probe restarts normal operation. Check connections before replacing the probe.

Temperature alarms "HA" and "LA" automatically stop as soon as the thermostat temperature returns to normal values or when the defrost starts.

Door switch alarm "dA" stop as soon as the door is closed.

External alarms "EAL", "BAL" stop as soon as the external digital input is disabled "PAL" alarm is recovered by switching OFF the instrument.

**TECHNICAL DATA**

**Housing:** self extinguishing ABS.

**Case:** facia 38x185 mm; depth 76mm

**Mounting :** panel mounting in a 150x31 mm panel cut-out with two screws. Ø 3 x 2mm.

Distance between the holes 165mm

**Protection:** IP20.

**Frontal protection:** IP65 with frontal gasket mod RG-L. (optional)

**Connections:** Screw terminal block ≤ 2,5 mm<sup>2</sup> heat-resistant wiring and 6,3mm Faston

**Power supply:** 230Vac or. 110Vac ± 10%

**Power absorption:** 7VA max.

**Display:** 3 digits, red LED, 14,2 mm high.

**Inputs:** 3 NTC probes

**Digital inputs:** 2 free voltage

**Relay outputs:** Total current on loads MAX. 20A

**compressor:** relay SPST 20(8) A, 250Vac

**light:** relay SPST 16(3) A, 250Vac

**fans:** relay SPST 8(3) A, 250Vac

**defrost:** relay SPST 8(3) A, 250Vac

**alarm:** SPST relay 8(3) A, 250Vac

**auxiliary:** SPST relay 16(3) A, 250Vac

**Other output :** alarm buzzer

**Serial output :** TTL standard

**Communication protocol:** Modbus - RTU

**Data storing:** on the non-volatile memory (EEPROM).

**Kind of action:** 1B.

**Pollution grade:** normal

**Software class:** A.

**Operating temperature:** 0÷60 °C.

**Storage temperature:** -25÷60 °C.

**Relative humidity:** 20÷85% (no condensing)


**Measuring and regulation range: NTC probe:** -40÷110°C (-58÷230°F)

**Resolution:** 0,1 °C or 1 °F (selectable).

**Accuracy (ambient temp. 25°C):** ±0,5 °C ±1 digit

**CONNECTIONS****XW270L/XW271L**

(\*) In XW271L, AUX is an anticondensing heater

**DEFAULT SETTING VALUES**

Label	Name	Range	Default	Level
<b>REGULATION</b>			"C/F	XW270L XW271L
Set	Set point	LS÷US	-5	Pr1 Pr1
Hy	Differential	0,1÷25,5 °C / 1÷45°F	2	Pr1 Pr1
LS	Minimum set point	-50,0°C÷SET / -58°F÷SET	-30	Pr2 Pr2
US	Maximum set point	SET + 110°C / SET + 230°F	20	Pr2 Pr2
OdS	Outputs activation delay at start up	0÷255 min.	1	Pr2 Pr2
AC	Anti-short cycle delay	0÷30 min.	1	Pr1 Pr1
CCT	Compressor ON time during fast freezing	0 ÷ 23h 50 min.	0	Pr2 Pr2
COn	Compressor ON time with faulty probe	0÷255 min.	15	Pr2 Pr2
COF	Compressor OFF time with faulty probe	0÷255 min.	30	Pr2 Pr2
<b>DISPLAY</b>				
CF	Temperature measurement unit	°C ÷ °F	°C	Pr2 Pr2
rES	Resolution (integer/decimal point)	in ÷ de	de	Pr1 Pr1
Lod	Local display	P1 ÷ Tr2	P1	Pr2 Pr2
Red	Remote display	P1 ÷ Tr2	P1	Pr2 Pr2
<b>DEFROST</b>				
tdF	Defrost type	rE, rT, in	rE	Pr1 Pr1
EdF	Defrost mode	In, Sd	In	Pr2 Pr2
SdF	Set point for SMART DEFROST	-30 ÷ +30°C / -22÷+86°F	0	Pr2 Pr2
dtE	Defrost termination temperature (1°Evaporator)	-50,0÷110°C / -58÷230°F	8	Pr1 Pr1
IdF	Interval between defrost cycles	1÷120h	6	Pr1 Pr1
MdF	(Maximum) length for 1° defrost	0÷255 min.	30	Pr1 Pr1
dFd	Displaying during defrost	rt, it, SEt, dEF, dEG	it	Pr2 Pr2
dAd	MAX display delay after defrost	0÷255 min.	30	Pr2 Pr2
Fdt	Draining time	0÷60 min.	0	Pr2 Pr2
dPO	First defrost after start up	n ÷ y	n	Pr2 Pr2
dAF	Defrost delay after fast freezing	0 ÷ 23h 50 min.	2	Pr2 Pr2
<b>FANS</b>				
FnC	Fans operating mode	C-n, C-y, O-n, O-y	O-n	Pr2 Pr2
Fnd	Fans delay after defrost	0÷255 min.	10	Pr2 Pr2
Fst	Fans stop temperature	-50,0÷110°C / -58÷230°F	2	Pr2 Pr2
<b>ALARMS</b>				
ALC	Temperature alarms configuration	rE÷Ab	rE	Pr2 Pr2
ALU	MAXIMUM temperature alarm	-50,0÷110°C / -58÷230°F	10	Pr1 Pr1
ALL	minimum temperature alarm	-50,0÷110°C / -58÷230°F	10	Pr1 Pr1
AFH	Temperature alarm and fan differential	0,1÷25,5 °C / 1÷45°F	2	Pr1 Pr1
ALD	Temperature alarm delay	0÷255 min.	15	Pr2 Pr2
dAO	Delay of temperature alarm at start up	0 ÷ 23h 50 min.	1,3	Pr2 Pr2
EdA	Alarm delay at the end of defrost	0÷255 min.	30	Pr2 Pr2
dot	Delay of temperature alarm after closing the door	0÷255 min.	15	Pr2 Pr2
dOA	Open door alarm delay	0÷255 min.	15	Pr2 Pr2
tBA	Alarm relay silencing	y ÷ n	y	Pr2 Pr2
nPS	Pressure switch activation number	0÷15	0	Pr2 Pr2
<b>ANALOGUE INPUTS</b>				
O1	Thermostat probe calibration	-12,0÷12,0°C / -21÷21°F	0	Pr1 Pr1
OE	Evaporator probe calibration	-12,0÷12,0°C / -21÷21°F	0	Pr2 Pr2
O3	Auxiliary probe calibration	-12,0÷12,0°C / -21÷21°F	0	Pr2 Pr2
P2P	Evaporator probe presence	n ÷ y	y	Pr2 Pr2
P3P	Auxiliary probe presence	n ÷ y	n	Pr2 Pr2
HES	Temperature increase during the Energy Saving cycle	-30÷30°C / -22÷86°F	0	Pr2 Pr2
<b>DIGITAL INPUTS</b>				
Odc	Open door control	no, Fan, CPr, F_C	Fan	Pr2 Pr2
I1P	Door switch polarity	CL÷OP	CL	Pr2 Pr2
I2P	Configurable digital input polarity	CL÷OP	CL	Pr2 Pr2
i2F	Digital input configuration	EAL, bAL, PAL, dFr, AUS, ES, OnF	EAL	Pr2 Pr2
ddI	Digital input alarm delay	0÷255 min.	5	Pr2 Pr2
SAA	Set point for anti-condensing heater	-50,0÷110°C / -58÷230°F	-20,0	---
<b>OTHER</b>				
Adr	Serial address	0÷247	1	Pr1 Pr1
rEL	Software release	---	1,0	Pr2 Pr2
PtB	Map code	---	---	Pr2 Pr2
Prd	Probes display	Pb1÷Pb3	---	Pr2 Pr2
Pr2	Access parameter list	---	---	Pr2 Pr2

Dixell s.r.l. Via dell'Industria, 27 - 32010 Z.I Pieve d'Alpago (BL) ITALY  
tel. +39 - 0437 - 98 33 - fax +39 - 0437 - 98 93 13 - E-mail:dixell@dixell.com - http://www.dixell.com